


ATV 4-Cycle Starting Procedures

Read your owner's manual! This is very important for proper operation and long life of your off-road vehicle.

- 1.) Check oil level in engine for proper level.
- 2.) Check all nuts/bolts and fasteners for proper tightness.
- 3.) Using proper charger, charge battery through one complete cycle of the battery charger.
- 4.) Fill fuel tank with premium unleaded fuel.
- 5.) Check tires for proper inflation.
- 6.) Insert key into ignition and turn to 'on' position.
- 7.) Pull in handbrake to set 'parking brake' by pulling on handle and pushing down 'parking lock' button.
- 8.) Pull up on choke lever (located on carburator).
- 9.) Check to see that the red kill switch is in the down position , otherwise unit will not start.
- 10.) Check safety tether under the seat (in rear) to make sure that it is pushed in completely, otherwise unit will not start.
- 11.) Push and hold red start button until engine fires (no longer than ten seconds at a time). You may need to push on the black throttle lever slightly to give the engine a little gas to help it start.
- 12.) When the engine starts running, you need to let the unit warm up two to three minutes while still having the choke in the 'up' position; up to ten minutes in cooler temperatures.
- 13.) After unit is warmed up, put the choke handle in the 'down' position.
- 14.) If you are starting the unit with the remote start, you will do all of the same steps except for pushing the red start button. Refer to owner's manual for directions on how to use remote or call Express Powersports at 815-933-3474.